

Eee 901 IDE2 to CF card

Signal	Eee 901 IDE2	CF Card	Signal	Eee 901 IDE2	CF Card
D00	1	21	D15	2	31
D01	3	22	GND	4	16
D02	5	23	D14	6	30
D03	7	2	D13	8	29
-ATA SEL(GND)	9	9	D12	10	28
D04	11	3	D11	12	27
D05	13	4	D10	14	49
GND	15	14	D09	16	48
Mechanical dir. Key					
D06	17	5	GND	18	17
D07	19	6	D08	20	47
GND	21	15	-RESET	22	41
PERn0(?)	23	-	-IOWR	24	35
PERp0(?)	25	-	GND	26	26
GND	27	1	-IORD	28	34
GND	29	50	REG(-DMACK)	30	44
PETn0(?)	31	-	INPACK(DMARQ)	32	43
PETp0(?)	33	-	GND	34	10
GND	35	35	USB D-	36	-
A00	37	20	USB D+	38	-
A01	39	19	GND	40	12
A02	41	18	IORDY	42	42
NC	43	-	INTRQ	44	37
-PDIAG	45	46	-CS0	46	7
VCC(-WE)	47	13	-CS1	48	32
VCC	49	36	GND	50	11
VCC	51	38	-DASP	52	45

CF Pin39 : Master/Slave

Open : Slave, GND : Master